



Plymasters

# Fixing Recommendations

## Glue and Pin



The Glue and Pin method of fixing plywood panels to your interior walls is the fastest and most cost effective way of doing it. You simply apply your preferred timber adhesive to the framing, line up your sheets and braid or pin them on. This leaves a very small pin hole in the face of the sheet which you can simply leave as is or fill with a matching wood filler. There are two ways of joining the sheets, you can make a feature of it by doing a negative detail. Simply paint the framing black and space the sheets 10mm apart to form a shadow line. Another way to achieve it is by cutting a very small chamfer on the outward facing corner of each joining sheet and then butt them up to create a small v groove between the sheets.

## Fastmount Concealed Fixing

Fastmount concealed panel mounting offers secure, hidden, removable fixings that allow installers to perfectly align each panel for a clean finish. Designed and manufactured in New Zealand, the clips allow individual panels to be removed with ease in a non-sequential system, so are capable of being replaced back in the exact position each time, or adjusted as needed. The precise positioning of each panel creates a consistently superior veneer across surfaces for a quality finish every time.

## Installation

Partial through section showing typical installation method

