



# Fixing Recommendations for Pre-Finished Panels

Plymasters has partnered with Soudal to provide the best recommendations for fixing our panels to timber framing/battens and uncoated timber walls.



## Plymasters Panels

- Classique Birch Pre
- Classique Canadian Oak Pre

## Soudal Glue Recommendations

- Gorilla FixALL Flexi
- Gorilla FixALL High Tack
- Soudal Soudaseal 240FC

---

## Preparation

Wipe the back of the prefinished panel with a solvent wipe.

Allow to evaporate completely from surface.

Ensure that walls/ framing/ battens are straight and level.

---

## Application

Apply 8mm x 8mm beads x 300mm length every 500mm down every framing stud or batten. Compress to 2mm minimum thickness.

---

## Fixing

Mechanically fix in place with appropriate panel pins.

