



Plymasters



Fixing Recommendations for Techno Veneers

Plymasters has partnered with Soudal to provide the best recommendations for fixing our techno veneer panels to sealed (non-porous) surfaces. When fixing the flexible TNT backed panels onto a wall, you can treat the product like wallpaper and use glue as an adhesive.

Soudal Glue Recommendations



Gorilla Contact Adhesive Aerosol 300ml

- Ideal for smaller areas that do not require a full Techno Veneer sheet



Gorilla Contact Industrial Spray Grade Adhesive 20L

Preparation

Surfaces must be cleaned and sealed (non-porous) including plaster boards and plaster stopped walls.

Key Notes

- Due to the nature of “Contact Adhesives” and their ability to absorb into porous substrates, all surfaces that it is applied to need to be sealed. This includes plasterboard and plaster stopped walls.
- Gorilla Contact Adhesive Aerosol can be removable if you only apply the Gorilla Contact Spray adhesive to a single surface.
- To remove excess Gorilla Contact Adhesive Aerosol, wipe off with thinners or an adhesive remover.

